


Item No.	Part No.	No. Used	Description	Item No.	Part No.	No. Used	Description
1	A346-07	1	Exhaust Valve Collar	22	A343-24	1	Gasket
2	A311-OK	2	O Ring 35.5-1.8	23	I22N-08	1	Body
3	A312-03	1	Cover Grip	24	A311-OU	1	O Ring 37.5-3.5
4	A200-20	1	Screw 5-3.5	25	A235-AO	1	Tail Cover
5	I230-NO	1	Exhaust Cover	26	B236-11	1	Air Plug with Duster
6	A343-29	1	Air Seal	27	A342-01	1	Nozzle
7	B346-06	1	Exhaust Valve Assy (Includes Items 79 & 80)	28	A206-29	1	Spring Pin 3-24
8	A210-25	1	Spring	29	A311-A2	1	O Ring 11-1.05
9	A311-OP	1	O Ring 9.8-2.4	30	A351-03	1	Upper Remote Housing
10	A311-96	2	O Ring 32-2.5	31	A210-A0	1	Conical Spring
11	A340-06	1	Head Valve Piston	32	A311-22	1	O Ring 1.9-1.2
12	A311-OR	1	O Ring 13-3	33	A251-16	1	Remote Core
13	A311-40	2	O Ring 26.59-2.95	34	A251-22	1	Remote Housing
14	A311-54	1	O Ring 22.9-2.7	35	A311-11	1	O Ring 9.8-1.9
15	A262-10	1	Piston Head	36	A210-02	1	Compression Spring
16	A260-20	1	Drive Blade	37	A250-04	1	Trigger A
17	A334-02	1	Sleeve Retainer	38	A350-04	1	Trigger B
18	A311-OT	1	O Ring 44.8-2.6	39	A281-22	1	Guide Plate
19	A344-02	1	Spacer	40	A210-96	1	Spring
20	A232-23	1	Cylinder	41	A280-47	1	Release Catch (B)
21	A341-21	1	Bumper	42	A207-23	1	Guide
				43	A290-14	1	Spacer



Item No.	Part No.	No. Used	Description	Item No.	Part No.	No. Used	Description
44	A200-09	2	Screw 5-20	71	BN01-10	1	Piston Assy (Includes Items 14 - 16)
45	A200-09	2	Screw 4-8	72	B232-23	1	Cylinder Set
46	A295-30	1	Driver Guide Cover				(Includes Items 10, 13 & 17 - 20)
47	A280-46	1	Release Catch	73	B351-03	1	Trigger Valve Set
48	A201-03	1	Screw 4-18				(Includes Items 30 - 35 & 77)
49	A294-44	1	Driver Guide	74	B271-96	1	Magazine Assy
50	A206-12	1	Inner Spring Pin 2.5-10	75	A205-04	1	E-Ring 2.5
51	A275-A1	1	Pusher	76	A206-65	1	Step Pin 5-27.3
52	A374-02	1	Spring Holder	77	A311-A1	1	O Ring 8-1
53	A349-04	1	Pad	78	A311-B9	2	O Ring 24.5-3
54	A276-24	1	Steel Bar	79	A311-OQ	1	O Ring 22-1.5
55	A204-02	1	Nylon Nut M5	80	A346-06	1	Exhaust Valve Set
56	A274-66	1	Magazine Support	81	A205-03	1	Washer #5-1.1t
57	A349-06	1	Belt Hook	<b>Accessories</b>			
59	A277-16	1	Click Lever	A01	<b>E112-00</b>	1	Oil Dispenser 20cc
60	A210-97	1	Spring	A02	191686-A	1	Safety Glasses
61	A335-01	1	Plastic Cover	A03	-----	1	Nails (See Catalogue for Details)
62	A206-49	1	Pin	A04	-----	1	Couplers (See Catalogue for Details)
64	A210-61	1	Compression Spring	A05	783201-2	1	Wrench
65	A278-21	1	Spacer		783202-0	1	Wrench
66	A203-27	1	Screw 4-25	A06	-----	1	Air Hose (See Catalogue For Details)
67	A349-05	1	Scale Board	A07	182935-8	2	Slide Lock
68	A203-28	1	Screw 3-12	A08	<b>E110-41</b>	1	Plastic Carrying Case
69	A312-04	1	Handle Grip				(Includes Item A07)
70	B340-06	1	Head Valve Piston Set (Includes Items 10 - 12 & 78)				